Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

21g

PITTSBURGH AUTOMOTIVE

60396

16' 6 Gauge Booster Cables



Visit our website at: http://www.harborfreight.com Email our technical support at: productsupport@harborfreight.com

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright[©] 2021 by Harbor Freight Tools[®]. All rights reserved.

No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein.

Tools required for assembly and service may not be included.

AWARNING

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Safety Warnings

- Shield eyes and face from batteries at all times. Wear ANSI-approved safety goggles and heavy-duty work gloves during use. Batteries produce explosive gasses.
- 2. Use only as intended.
- 3. Be sure vent caps are tight and level. Place damp cloth over any vent caps on both batteries. Handle cloth carefully do not allow cloth to come in contact with eyes, skin or clothing.
- 4. Do not allow red and black cable clamps to touch each other or same metal object during use.
- 5. Be sure vehicles do not touch and both electrical systems are off and the same voltage.
- 6. Be careful to avoid moving fan blades.
- Check polarity of battery posts.
 POSITIVE (POS, P, +) battery post usually has larger diameter than NEGATIVE (NEG, N, -) post.
- 8. Inspect before every use; do not use if parts loose or damaged.
- 9. Consult Automobile Owner's Manual and Follow All Instructions.

Specifications


Capacity	200 Amp
Cable	16 ft 6 AWG

Instructions

Vehicle batteries may be negative or positive post grounded. Consult your automobile owner's manual before selecting the method to follow for cable connections.


Note: The vast majority of modern vehicles use a negative ground system.

Negative Ground System



- Connect positive (+) cable to positive (+) terminal of discharged battery.
- Connect other end of positive cable to positive terminal of booster battery.
- Connect second cable (negative) to other terminal (negative) of booster battery.
- 4. MAKE FINAL CONNECTION ON ENGINE BLOCK OF STALLED VEHICLE (NOT TO NEGATIVE POST) AWAY FROM BATTERY.
- 5. STAND BACK.
- Start vehicle and remove cables in reverse order of connection, disconnecting from engine block first.

Positive Ground System



- Connect negative (-) cable to negative (-) terminal of discharged battery.
- Connect other end of negative cable to negative terminal of booster battery.
- Connect second cable (positive) to other terminal (positive) of booster battery.
- 4. MAKE FINAL CONNECTION ON ENGINE BLOCK OF STALLED VEHICLE (NOT TO POSITIVE POST) AWAY FROM BATTERY.
- 5. STAND BACK.
- Start vehicle and remove cables in reverse order of connection by disconnecting engine block connection first.

Record Product's Serial Number	er
Here:	

Note: If product has no serial number, record month and year of purchase instead.

Note: Parts shown for illustration purposes only, and are not available individually as replacement parts. Refer to UPC 193175436054.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

