

1. Mount to solid wood surface, if possible.
2. Position Key Box in desired location and mark location of mounting holes (drilled holes should be smaller than screws).
3. Drill holes, set Box against wall and install screws, mounting Box into place.
4. Note: If mounting to drywall, insert screw anchors into drill holes before putting in screws. (Required screws and anchors may not be included).