



ASSEMBLING INSTRUCTION

1. PUT LONG FRAMES B ONTO SHORT FRAMES A
2. PUT CASTORS C ONTO LONG FRAMES
3. PUT SPRING WASHERS E ON THE BOLTS D THAT IS FIXED ON SHORT FRAMES GO THROUGH LONG FRAMES HOLES
4. THEN PUT ON FLAT WASHER F OVER THE SPRING WASHER
5. PUT THE NUT G OVER THE FLAT WASHER AND TIGHTEN THEM

PART LIST

| PARTS | QTY |
|---------------------------|-------|
| A: SHORT FRAMES W/ CARPET | 2PCS |
| B: LONG FRAMES | 2PCS |
| C: CASTORS | 4PCS |
| D: BOLTS | 16PCS |
| E: SPRING WASHERS | 16PCS |
| F: FLAT WASHERS | 16PCS |
| G: NUTS | 16PCS |