

Customizing the Foam Insert

1. Place item(s) on top of foam in the desired packing position. Leave enough space for complete foam blocks between each item and between items and the sides of the case.
2. Trace the outline of each item on the foam using a marker or soft pencil.
3. Remove the marked blocks to customize the foam insert. Leave more blocks in place around the edges for a tighter fit.

Note: Reference UPC 193175443540.