


Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

19f

REMOTE CONTROL STUNT CAR



Visit our website at: <http://www.harborfreight.com>
Email our technical support at: productsupport@harborfreight.com

56166

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright© 2019 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠WARNING

Read this material before using this product.
Failure to do so can result in serious injury.
SAVE THIS MANUAL.

Specifications

Batteries Required	3x "AA" Batteries (for Car) 2x "AA" Batteries (for Remote)
Frequency	27MHz

Important Safety Information

- 1. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**
- 2. Follow basic safety precautions to reduce the risk of personal injury and/or damage to the product during use.**
- 3. Do not allow children younger than age 5 to use this Stunt Car.** Children should not operate without adult supervision.
- 4. Keep out of reach of children younger than 3.** Contains small parts that may present a choking hazard.
- 5. Do not swing Remote Antenna near your face or near other people.**
- 6. Keep spectators and pets away.** Spectators should only watch from a safe distance.
- 7. Do not mix old and new batteries.** Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Position batteries in proper polarity. Do not use swollen or leaking batteries.
- 8. Do not open the Stunt Car's housing or modify its design.** Doing so may cause damage and/or make it dangerous.
- 9. Do not use if parts are loose or damaged.** If the toy has been damaged, immediately stop using it.
- 10. Only use outside or in large, enclosed area.** Do not drive near open flames, pets, or delicate furniture.
- 11. If you lose control of the Stunt Car, release the buttons.**
- The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.
- 13. Maintain product labels and nameplates.** These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.

Unpacking

1. Carefully slide the cardboard support containing the Stunt Car out of the packaging.
2. Remove the Remote.
3. Remove the Stunt Car from the cardboard. If any part does not slide out easily, stop and clear the obstruction before proceeding.

Installing Batteries


Remote

1. Unscrew and remove the battery cover on the back of the Remote.
2. Insert 2 AA batteries (not included) into battery compartment, following indicated polarity.
3. Replace the Remote battery cover.

Stunt Car

1. Unscrew and remove the battery cover from the bottom of the Stunt Car. See below.
2. Insert three "AA" batteries (not included) into the battery compartment, following the indicated polarity.

Battery Cover



CAUTION! Replace all batteries at one time. All batteries must be of the same type and charge level.

3. Replace the battery compartment on bottom side of the Stunt Car.
4. Screw cover on securely.

Operation


CAUTION! Keep spectators a safe distance away during use.

Note: Read through this section completely and get familiar with the controls BEFORE using Stunt Car.

1. Turn Car Switch on.
2. Place Stunt Car on floor with wheels down.

Note: Each Remote control stick corresponds to one set of wheels on the Stunt Car.


3. To move Stunt Car forward, push Left control stick up. To move Stunt Car backward, push Left control stick down. See below.




4. To flip the front wheels to the left, push the Right control stick to the left. To flip the front wheels to the right, push the Right control stick to the right.

Note: Flipping the wheels in either direction continuously will turn the Car in a complete circle.

5. To make the Car do a front flip to the left, push Left control stick up and Right control stick to the right. See below.



6. To make the Car do a front flip to the right, push Left control stick up and Right control stick to the left.



7. To stop the Stunt Car, release the buttons.

Note: If the Stunt Car rolls onto its back, the small trick wheels will allow it to continue moving.

8. To make the front wheels spin in this position, push Right control stick to the left or right. See below.



9. After use, turn Car Switch off. Store indoors, away from water, out of the reach of children.

Maintenance

1. Keep the Stunt Car clean and dry.
2. Store the Stunt Car out of the reach of children.
3. Properly recycle all used batteries.

Record Serial Number Here:

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available.

FCC NOTICE:

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

26541 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797