

Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

19e

ROCK CRAWLER



Visit our website at: <http://www.harborfreight.com>
Email our technical support at: productsupport@harborfreight.com

56514

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright© 2019 by Harbor Freight Tools®. All rights reserved.

No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠WARNING

Read this material before using this product. Failure to do so can result in serious injury. **SAVE THIS MANUAL.**

Specifications

Batteries Required	4x "AA" Batteries (for Truck) 2x "AA" Batteries (for Remote)
Frequency	27 MHz

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Important Safety Information

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**
- Follow basic safety precautions to reduce the risk of personal injury and/or damage to the product during use.**
- Do not allow children younger than age 6 to use this Truck.** Children should not operate without adult supervision.
- Keep out of reach of children younger than 3.** Contains small parts that may present a choking hazard.
- Keep spectators and pets away.** Spectators should only watch from a safe distance.
- Do not mix old and new batteries.** Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Position batteries in proper polarity. Do not use swollen or leaking batteries.
- Do not open the Truck's housing or modify its design.** Doing so may cause damage and/or make it dangerous.
- Do not use if parts are loose or damaged.** If the toy has been damaged, immediately stop using it.
- Only use outside or in large, enclosed area.** Do not drive near open flames, pets, or delicate furniture.
- If you lose control of the Truck, release the switches.**
- The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.
- Maintain product labels and nameplates. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.

Assembly

Unpacking

- Carefully slide the cardboard support containing the Truck out of the packaging.
- Remove the Remote.
- Remove the Truck from the cardboard. If any part does not slide out easily, stop and clear the obstruction before proceeding.

Installing Batteries

Remote


1. Unscrew and remove the battery cover on the back of the Remote.
2. Insert two AA batteries (not included) into battery compartment, following indicated polarity.
3. Replace the Remote battery cover and screw it on securely.

Truck

1. Turn Truck over on its top.
2. To remove the battery cover, unscrew the single screw on the right side and disengage latch marked 'Open.' See below.
3. Insert four "AA" batteries (not included) into the battery compartment, following the indicated polarity.

CAUTION! Replace all batteries at one time. All batteries must be of the same type and charge level.

4. Replace battery cover on bottom side of the Truck and ensure that latch marked 'Open' is secured in place.
5. Screw cover on securely.



Operation


Operating Truck

CAUTION! Keep spectators a safe distance away during use.

Note: Read through this section completely and get familiar with the controls BEFORE using Truck.

1. Place Truck on a flat surface and stand behind it with the tail pointing towards you.
2. To move Truck forward, push Left control stick up. To move Truck backward, push Left control stick down.
3. To steer Truck to the right, push the Left stick up while pushing the Right stick to the right.
4. To steer Truck to the left, push the Left stick up while pushing the Right stick to the left.
5. To stop the Truck, release control sticks.

Note: If the Truck will not stay straight when moving forward, use the Front Wheel Alignment Lever to adjust alignment of the front wheels.



6. After use, turn power switch off. Store indoors, away from water, out of the reach of children.

Maintenance

1. Keep the Truck clean and dry.
2. Store the Truck out of the reach of children.
3. Properly recycle all used batteries.

Record Serial Number Here:

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.