

Owner's Manual & Safety Instructions


Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

19k

luminar INDOOR™

56833

WARM WHITE FAIRY STRING LIGHTS WITH REMOTE



Visit our website at: <http://www.harborfreight.com>
Email our technical support at: productsupport@harborfreight.com






When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

⚠ WARNING

Read this material before using this product. Failure to do so can result in serious injury. **SAVE THIS MANUAL.**

Copyright © 2019 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

WARNING SYMBOLS AND DEFINITIONS

	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
	Addresses practices not related to personal injury.

IMPORTANT SAFETY INFORMATION

WARNING

Read all safety warnings and instructions.

Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

1. Choking hazard! Keep out of reach of children.
2. Do not touch, operate, or install fixture while in contact with water. Not intended for illumination of aquariums. Do not mount over sinks or stoves.
3. Keep installation area clean. Cluttered areas invite accidents.
4. Do not overreach. Keep proper footing and balance at all times. If a ladder is to be used during installation, it should be supported by an assistant.
5. Use as intended only.
6. Maintain labels and nameplates. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.
7. The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.
8. Keep batteries out of reach of children. Keep batteries in original package until ready to use. Discard used batteries immediately. Do not allow children to play with devices containing batteries.
9. Do not install old and new batteries together. Do not install alkaline, carbon-zinc or rechargeable batteries together. Position batteries in proper polarity. Do not use swollen or leaking batteries.



SAVE THESE INSTRUCTIONS.

Specifications

String Light Length	20 ft. 2 in.
Battery (String Lights)	3 x AA (sold separately)
Battery (Remote Control)	Li-Ion CR2025

luminar **INDOOR™**



Read the **ENTIRE IMPORTANT SAFETY INFORMATION** section at the beginning of this manual including all text under subheadings therein before set up or use of this product.


Installation

1. Select the location for the String Lights.
2. Carefully unwind the String Lights and place in the desired location. Avoid any tripping hazard.
3. Install batteries into the Battery Box being careful to adhere to polarity. Close both locks on box.
4. Place the Battery Box in a secure location being sure its power cord is not strained. The Battery Box may be hung by its handle, if desired.

Operation

1. Pull the battery tab out of the Remote Control.
2. Point the top of the **Remote Control** at the String Lights and turn lights on by pressing the ON button.
3. Use the Remote Control to turn the String Lights on/off and select mode changes.
4. Turn off the String Lights by pressing the OFF button.


Note: The Remote Control must have a direct line of sight to the Lights.



Button	Selection	
ON	Turns lights On	
TIMER	When enabled, lights 6hr on and 18hr off	
OFF	Turns lights Off	
MODE	1	Combination
	2	Waves
	3	Sequential
	4	Slow Glow
	5	Chasing Flash
	6	Slow Fade
	7	Twinkle Flash
	8	Steady on
DIM	-	Decreases light intensity
	+	Increases light intensity

Battery Box

Instead of the Remote Control, the button on the top of the **Battery Box** may be used to control the String Lights. Press the Control Button to toggle the lights on and off, and cycle through the modes.



Press	Mode
Once	Combination
Twice	Waves
3	Sequential
4	Slow Glow
5	Chasing Flash
6	Slow Fade
7	Twinkle Flash
8	Steady on
9	Off

Maintenance and Servicing



Procedures not specifically explained in this manual must be performed only by a qualified technician.

WARNING

TO PREVENT SERIOUS INJURY FROM TOOL FAILURE:


Do not use damaged equipment. If abnormal noise or vibration occurs, have the problem corrected before further use.

Cleaning, Maintenance, and Lubrication

1. **BEFORE EACH USE**, inspect the general condition of the tool. Check for:
 - loose hardware,
 - misalignment or binding of parts,
 - cracked or broken parts, and
 - any other condition that may affect its safe operation.
2. LEDs gradually emit less light over their lifetime.
3. **PERIODICALLY**, clean Lights, Battery Box, and Remote Control using a mild, nonabrasive cleaner and clean soft cloth.


Replacing the Battery in the Remote Control

1. Access the battery from the back of the Remote Control.
2. Push the release button to the right and carefully slide out the battery drawer.
5. Slide drawer closed until it snaps in place.
6. Battery must be recycled or disposed of properly. Keep out of reach of children.



3. Remove the old battery, noting polarity (positive "+" faces up).
4. Place the new CR2025 battery in drawer with "+" facing up.

Troubleshooting

Problem	Possible Causes	Likely Solutions
Lights won't turn on.	<ol style="list-style-type: none">1. Battery tab not removed.2. Battery Box batteries improperly installed or old.	<ol style="list-style-type: none">1. Check that the battery tab is pulled from the Remote Control.2. Properly install batteries or replace.
 Follow all safety precautions whenever diagnosing or servicing the tool.		

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Record Product's Serial Number Here: _____


Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.

Parts List and Diagram

Part	Description	Qty
1	Lock 1	1
2	Lock 2	1
3	Battery Box Bottom	1
4	Battery, AA (x3, sold separately)	0
5	PCB Assembly	1
6	Bulkhead	1

Part	Description	Qty
7	Silicone Ring	1
8	Battery Box Top	1
9	Silicone Cap	1
10	Remote Control	1
11	String Lights	1
12	Battery, Li-Ion CR2025	1



Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



26541 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797