



COAXIAL CRIMPER

Model 57195

## OPERATION INSTRUCTIONS



26541 Agoura Road, Calabasas, CA 91302

Visit our website at: <http://www.harborfreight.com>

Copyright© 2007 by Harbor Freight Tools®. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

**For technical questions or replacement parts, please call 1-888-866-5797.**

---

## OPERATION

---

**WARNING!** Disconnect power before working on cables.

**CAUTION!** Wear ANSI-approved safety goggles and heavy-duty work gloves.

1. Strip 0.25" through shield braid and inner foam insulation of cable to center conductor. Strip 0.25" more back, but do not pierce shield braid.
2. Fan shield braid back from inner insulation.
3. Insert the cable into the Connector until the inner insulation is even with the hole.
4. Insert the cable and Connector into the Crimper and squeeze handles together until the Connector is firmly attached to the cable.
5. Pull on the Connector to ensure it is solidly connected.  
If Connector moves, repeat steps 1 - 4.

