

Kenway™


LED UNIVERSAL RECTANGULAR 6 FUNCTION TAIL SIGNAL LIGHT

Power	12 VDC Only (Negative Ground Only)
-------	------------------------------------

WARNING! TO PREVENT SERIOUS INJURY AND PROPERTY DAMAGE: Install according to DOT guideline. Do not cut or rewire any part of the tail light. Wear ANSI-approved safety goggles during installation. Inspect before every use, do not use if damaged. Do not submerge.

Installation

1. Disconnect vehicle power supply.
2. Select Light location.
3. Use Light mounting posts as template to mark mounting holes. Drill three 1/4" holes and attach Light using supplied hardware. Tighten securely.
4. Connect wires:
 - a. Red - Brake/Turn Lights
 - b. Yellow - Back-up Lights
 - c. Black - Tail Lights
 - d. White - Ground
5. Reconnect vehicle power supply.
6. Test all Light functions.



Maintenance

1. Test all Light functions before each use.
2. Periodically check for loose hardware, damaged electrical wiring, cracked or broken parts, and any other condition that may affect its safe operation.
3. Clean external surface with clean, dry cloth.

UPC 193175434289
20J **58213**