Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

21h

SUPERIOR AUTOMOTIVE TOOLS Inner Tie Rod Tool Set



Visit our website at: http://www.harborfreight.com Email our technical support at: productsupport@harborfreight.com

58391

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright[©] 2021 by Harbor Freight Tools[®]. All rights reserved.

No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein.

Tools required for assembly and service may not be included.

AWARNING

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Important Safety Information

- Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- Keep children and bystanders away while using this product. Distractions can cause you to lose control.
- Stay alert, watch what you are doing and use common sense when using this product. Do not use this product while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while using this product may result in serious personal injury.
- Use safety equipment. Always wear eye protection. Safety equipment such as non-skid safety shoes, hard hat, or heavy-duty work gloves used for appropriate conditions will reduce personal injuries.
- Do not overreach. Keep proper footing and balance at all times. This enables better control of this product in unexpected situations.
- Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts.
- Do not force this product. Use the correct product for your application. The correct product will do the job better and safer at the rate for which it was designed.
- Store this product out of the reach of children and do not allow people unfamiliar with the product or these instructions to operate the product. This product could be dangerous in the hands of untrained users.

- Maintain this product. Check for misalignment or binding of parts, breakage of parts and any other condition that may affect the product's operation. If damaged, have this product repaired before use. Many accidents are caused by poorly maintained equipment.
- 10. Use this product in accordance with these instructions and in the manner intended for this particular type of product, taking into account the working conditions and the work to be performed. Use of this product for operations different from those intended could result in a hazardous situation.
- Maintain labels and nameplates on the Inner Tie Rod Tool. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.
- Wear ANSI-approved safety goggles and heavy-duty work gloves when using this product.
- 13. Turn off the vehicle's engine and refer to the vehicle's service and repair manual for instructions on how to safely secure the vehicle in place with jack stands.
- 14. The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur.

It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

Specifications

Applications	For use with rack and pinion assemblies on front wheel drive vehicles. Not for use with "Saginaw" type rack and pinion assemblies. For hand use only. Not for use with power tools (impact wronghes, etc.)
	For hand use only. Not for use with power tools (impact wrenches, etc.)



Operating Instructions



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

Note: Applications and operating procedures can differ depending on the make and model of vehicle. A generalized description of procedures is as follows:

- 1. Remove the wheel from the vehicle.
- Refer to vehicle's service and repair manual to remove outer tie rods.
- 3. Place Sleeve (2) onto Socket (1) and align notches.
- Place correct size Crowfoot onto inner tie rod.
- Hold on to Crowfoot while sliding Socket over inner tie rod. When socket engages with crowfoot, rotate Sleeve to lock in Crowfoot.

- Bend locking tab on inner tie rod fitting so that inner tie rod can be removed.
- Insert appropriate tool into 1/2" drive and turn Socket counterclockwise to remove inner tie rod.
- Refer to vehicle's service
 and repair manual to replace
 inner and outer tie rod.

Note: Have the wheels aligned by a qualified technician.



Maintenance and Servicing

- Before each use, inspect general condition of tool. Check for misalignment or binding of moving parts, cracked or broken parts, and any other condition that may affect its safe operation. <u>Do not</u> use damaged equipment.
- 2. After use, wipe parts with clean cloth.
- When storing, keep Inner Tie Rod and its accessories in its Carrying Case and store in a clean, dry, safe location out of children's reach.

<u>CAUTION!</u> All maintenance, service, and repairs not mentioned in this manual must only be performed by a qualified service technician.




Parts List

Part	Description	Qty
1	Socket	1
2	Sleeve	1
3	1-3/16" Crowfoot Wrench	1
4	1-1/4" Crowfoot Wrench	1
5	1-5/16" Crowfoot Wrench	1
6	1-3/8" Crowfoot Wrench	1
7	1-7/16" Crowfoot Wrench	1

Part	Description	Qty
8	1-1/2" Crowfoot Wrench	1
9	29 mm Crowfoot Wrench	1
10	32.5 mm Crowfoot Wrench	1
11	33.5 mm Crowfoot Wrench	1
12	38.4 mm Crowfoot Wrench	1
13	40 mm Crowfoot Wrench	1
14	42 mm Crowfoot Wrench	1

Record Product's Serial Number Here:

<u>Note:</u> If product has no serial number, record month and year of purchase instead



90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

