# Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

21h

# UNDERHOOD RECHARGEABLE WORK LIGHT



(BC)

Visit our website at: http://www.harborfreight.com Email our technical support at: productsupport@harborfreight.com 58424

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright<sup>©</sup> 2021 by Harbor Freight Tools<sup>®</sup>. All rights reserved.

No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein.

Tools required for assembly and service may not be included.

# **AWARNING**

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

# **Specifications**

Battery	Li-ion	
Battery Rating	7.4V, 5200mAh	
Charge Time	2 h 45 m	
Run Time	4 h (high) 13 h 30 m (low)	
Kelvin Rating	7000K	

# **IMPORTANT SAFETY INFORMATION**

# **AWARNING**

### To prevent serious injury, FIRE, and EXPLOSION:

- Keep dry. Do not open, drop, short-circuit, incinerate, expose to temperatures higher than 140° F, or charge/use if damaged.
- 2. Only use included charging adaptors. Other adaptors may damage tool or cause fire.
- 3. Do not submerge Light.
- 4. Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.
- 6. Not a toy. Keep out of reach of children.
- Contains Li-Ion battery. Battery must be recycled or disposed of properly. Do not open, crush, heat above 140° F (for Li-Ion) or incinerate.

### **Charging Instructions**



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

- Insert the end of the Adaptor cord into the Charging Jack, located in one of the handgrips.
- 2. Plug the AC/DC Adaptor into a 120V outlet.
- The Charge Light Indicator will light up during charging. After approximately 2 h 45 m, all four lights on the Charge Light Indicator should be lit up, indicating the Work Light is fully charged and ready for use. Unplug the Adaptor.

NOTE: Do not leave the Battery in a discharged state. Charge the Battery every 3 months if the Work Light is not in use. This will keep the Battery from wearing down and add to its life. Do not charge the Work Light at temperatures below 40° F.

### **Operation Instructions**



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

**NOTE:** Before using Work Light for the first time, fully charge the Battery.

- Press On/Off Switch once to turn Light on. Light will turn on in low brightness mode.
- Press On/Off Switch a second time to change to high brightness.
- 3. Press On/Off Switch a third time to turn the Light off.
- Length can be adjusted by pulling on the hooks.
   Maximum length is 85". Use hooks to attach Light to desired position, such as a lifted car hood.
- When Light is in place, Light can be rotated to desired position by twisting. Light will click into place as you rotate it.
- When finished using the Work Light, store indoors away from children.

# **Battery Removal**

- Contains Li-Ion Battery. Battery must be recycled or disposed of properly.
- To remove Battery, make sure Light is off and disconnected from Adaptor.
- 3. Open Housing to access Battery.

**Note:** Light is not user serviceable, only open housing to remove Battery.

 Cut wires attached to Battery. Battery may be adhered to housing. Carefully pry Battery out of housing.

## **Limited 90 Day Warranty**

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Record I	Product	's Serial N	√umber	Here:
----------	---------	-------------	--------	-------

Note: If product has no serial number, record month and year of purchase instead.

**Note:** Replacement parts are not available for this item.

Note: Reference UPC 193175438997.



26541 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797