Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.



800 LUMEN RECHARGEABLE SLIM BAR LIGHT

23g

59103

вс

Visit our website at: http://www.harborfreight.com Email our technical support at: productsupport@harborfreight.com

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright[®] 2023 by Harbor Freight Tools[®]. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

201

Input Rating	5VDC / 1000mA
Battery	18650 Li-ion
Battery Rating	3.7V / 2600mAh
Charge Time	4 hours

IMPORTANT SAFETY INFORMATION

AWARNING

To prevent serious injury, FIRE, and EXPLOSION:

- 1. Keep dry.
- 2. Only use included charging adaptors. Other adaptors may damage tool or cause fire.
- 3. Do not submerge Light.
- 4. Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.
- 6. Not a toy. Keep out of reach of children.
- Contains Li-lon battery. Battery must be recycled or disposed of properly. Do not open, crush, heat above 140° F or incinerate.

Charging Instructions



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

NOTE: Before using Light for the first time, fully charge the Battery.

1. Plug Adaptor into Charging Jack.



- 2. Plug Adaptor into a grounded 120VAC outlet.
- The Charge Indicator on Adaptor will turn Red during charging. When charging is done, it will turn Green. Unplug the Adaptor.

NOTICE: Do not leave the Battery in a discharged state. Charge the Battery every 3 months if the Work Light is not in use. This will keep the Battery from wearing down and add to its life. Do not charge the Light at temperatures below 40° F.

Record Product's Serial Number Here:_

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available for this item. Refer to UPC 193175520036.

Operation Instructions



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

NOTE: Before using Light for the first time, fully charge the Battery.

NOTE: Light is equipped with smart memory function. If Light stays on a mode more than five seconds, that mode will be memorized. Light will directly turn off when Light is pressed. Light will turn on to the memorized mode when Power Button is pressed next.

- 1. Press Power Button.
 - a. One time to turn on the top light.

- b. Two times to switch to front flood light Eco mode.
- c. Three times to switch to front flood light full power mode.
- d. Four times to switch to rear flood light Eco mode.
- e. Five times to switch to rear flood light full power mode.
- f. Six times to turn light off.
- 2. When finished using Light, store indoors away from children.

Battery Removal and Replacement

NOTE: Contains Li-lon battery. Battery must be recycled or disposed of properly. Do not open, crush, heat above 140° F or incinerate.

- 1. Unplug Adaptor from Light.
- 2. Remove Screw from Screw Cap.



3. Pull Screw Cap out of opposite side.




4. Remove three more Screws.



Note: Keep track of Screw location.

- 5. Gently pull top from bottom to seperate.
- 6. Separate top half exposing Circuit Board.



- 7. Disconnect Battery wires from Circuit Board.
- 8. Remove or Replace Battery

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



26677 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797