

Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

22d

BRAUN™

WATERPROOF RECHARGEABLE SPOTLIGHT



Visit our website at: <http://www.harborfreight.com>
Email our technical support at: productsupport@harborfreight.com

59224

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright© 2021 by Harbor Freight Tools®. All rights reserved.

No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠WARNING

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

IMPORTANT SAFETY INFORMATION

⚠ WARNING

To prevent serious injury, FIRE, and EXPLOSION:

1. Only use included charging adaptors. Other adaptors may damage tool or cause fire
2. Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
3. People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.
4. Not a toy. Keep out of reach of children.
5. Contains Li-Ion battery. Battery must be recycled or disposed of properly. Do not open, crush, heat above 140° F or incinerate.

Specifications

Battery	Li-Ion, 7.4V, 4400 mAh
Bulb Type	LED
Charge Time	6.5 to 7 hours
Input Rating	5VDC, 2A

Setup - Before Use

Functions



Operating Instructions




Read the **ENTIRE IMPORTANT SAFETY INFORMATION** section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Charging the Battery

Note: Before using light for the first time, fully charge the battery.

1. Open the Charge Port Cover using a suitable tool.
2. Plug one end of USB adapter into Charging Jack. Plug other end to a 5VDC 2A source.
3. When all 4 LED charge lights turn blue, the Battery is fully charged.
4. Disconnect the USB Cable.
5. Close the Charge Port Cover
6. To maintain waterproof seal, use a suitable tool to tighten screw on Charge Port Cover. Do not overtighten.



NOTICE: Do not leave the Battery in a discharged state. Charge the Battery every 3 months if the Spotlight isn't in use. This will keep the Battery from wearing down and add to its life.

General Operating Instructions

1. Hold the Spotlight using the Hand Grip.
2. Move the Lock Switch UP to unlock it and then turn ON the Spotlight by squeezing the Trigger.
3. Select the desired light output using the Trigger: One press for low beam, two for medium beam, three for high beam, four for SOS and five for strobe. The sixth press turns the light OFF.
4. Use the Lock Switch to lock the light on or off. When the Lock Switch is moved DOWN, the Trigger is locked in its last setting.

Note: The Spotlight can sit on its back and can float in water.



Note: The Spotlight's Stand / Hanger can be adjusted, extended and positioned as desired or hung.




Stand / Hanger

5. When finished using the Spotlight, turn it OFF and lock Trigger to prevent accidental operation.
6. After use, wipe Spotlight with a clean soft cloth and store indoors out of children's reach.

Battery Removal

Note: Contains Li-ion battery. Battery must be recycled or disposed of properly. Do not open, crush, heat above 140° F or incinerate.

1. Remove the front lens cover by unscrewing it.
2. Remove the reflector.
3. Remove the six screws holding the heat sink in place.
4. Gently remove the heat sink to expose the battery.
5. Cut the two wires connected to the battery one at a time.
6. Gently pull the battery out of light housing.



Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Record Product's Serial Number Here: _____

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available for this item. Reference UPC 193175460547

BRAUN™

26677 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797