

Copyright[®] 2022 by Harbor Freight Tools[®]. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Specifications

Input Rating	5VDC, 1A
Battery	Li-Ion 3.7V, 2600mAh
Charge Time*	4hr 15min
Run Time	2 hr (high mode)

*Note: Charge time will vary depending on the amp rating of the USB port the cord is attached to.

IMPORTANT SAFETY INFORMATION

AWARNING

To prevent serious injury, FIRE, and EXPLOSION:

- 1. Keep dry.
- 2. Only use included charging adaptors. Other adaptors may damage tool or cause fire.
- 3. Do not submerge Light.
- 4. Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.
- 6. Not a toy. Keep out of reach of children.
- Contains Li-lon battery. Battery must be recycled or disposed of properly. Do not open, crush, heat above 140° F or incinerate.

Record Product's Serial Number Here:

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available.

Note: Yellow Floodlight (59587): UPC 193175476463 Green Floodlight (59226): UPC 193175460561 Blue Floodlight (59225): UPC 193175460554 Red Floodlight (59227): UPC 193175460578

Charging Instructions

<u>NOTE</u>: Before using the Light for the first time, fully charge the Battery.

- 1. Turn Light off and remove Charging Port Cover. Plug the USB Charging Cable (included) into the Charging Port.
- 2. Plug the other end of the USB Charging Cable into a powered USB port.
- 3. LEDs will blink green during charging. When charging is done, LEDs will be solid green.
- Unplug the USB Charging Cable and replace cover on Charging Port.


NOTICE: Do not leave the Battery in a discharged state. Charge the Battery every 3 months if the Light is not in use. This will keep the Battery from wearing down and add to its life.

Operation



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

- 1. Press the Power Button for low, again for medium, again for high and again to turn off.
- When the Light is on, the three LEDs indicate battery level. Charge battery when all indicator LEDs are off and Light will not turn on.
- 3. When finished using the Light, turn it off and store indoors away from children.





Battery Removal

 Contains Li-Ion battery. Battery must be recycled or disposed of properly. Do not open, crush, heat above 140° F or incinerate.


2. Turn Light off. Remove four screws and cover.

- 3. Remove four screws from internal cover. Remove internal cover.
- 4. Cut battery wires.



Remove four screws





Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



26677 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797