

rovements, actual product may differ slightly from the product describe Tools required for assembly and service may not be included.

### Specifications

Input Rating	5VDC, 1A
Battery	Li-ion 3.7V, 2200mAh
Charge Time	4 hours

# **IMPORTANT SAFETY INFORMATION**

## **AWARNING**

#### To prevent serious injury, FIRE, and EXPLOSION:

- Keep dry. Do not open, drop, short-circuit, incinerate, expose to temperatures higher than 140° F, or charge/use if damaged.
- 2. Do not submerge Light.
- 3. Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- 4. Do not charge for longer than 4 hours. Overcharging will cause overheating and shorten battery life.
- People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.
- 6. Not a toy. Keep out of reach of children.

### **Charging Instructions**



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

- 1. Insert the end of the Charging Cable into the Charging Jack, located on the side of the handle, under a cover.
- 2. Plug Charging Cable into a powered USB port.
- The Charging Indicator on the Button will light up Red during charging. After approximately 4 hours the Charging Indicator turns Green, indicating the Work Light is charged and ready for use. Unplug the Charging Cable.

**NOTICE:** Do not leave the Battery in a discharged state. Charge the Battery every 3 months if the Work Light is not in use. This will keep the Battery from wearing down and add to its life. Do not charge the Work Light for more than 4 hours. Overcharging will cause overheating and shorten battery life. Do not charge the Work Light at temperatures below 40° F.

### **Battery Replacement**

- 1. Unthread the base of the flashlight.
- 2. Remove the old battery, noting polarity.
- 3. Insert a new 3.7V, 2200mAh li-ion battery into the flashlight, positive end first.

#### **Operation Instructions**



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

**Note:** Before using Work Light for the first time, fully charge the Battery.

- 1. Press the Button once to turn on the light.
- 2. Press the Button again to switch to economy mode.
- 3. Press the Button a third time to turn on the light on the end of the bar.
- 4. Press the Button a final time to turn the light off.

5. When finished using the Work Light, store indoors away from children.

<u>Note:</u> If the light will not turn on, check that the Battery Cap is tight. The Button may need to be pressed forcefully to turn the light on.

 Li-Ion BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.
Do not short, incinerate or open battery.

**Record** Product's Serial Number Here:

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available for this item. Refer to UPC 193175473547.

#### Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



26677 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797