Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.



Visit our website at: http://www.harborfreight.com Email our technical support at: productsupport@harborfreight.com

59544

22f

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright[©] 2022 by Harbor Freight Tools[®]. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

WARNING SYMBOLS AND DEFINITIONS			
A	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.		
	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.		
	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.		
	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.		
NOTICE CAUTION	Addresses practices not related to personal injury.		

IMPORTANT SAFETY INFORMATION

Read all safety warnings and instructions. *Failure to follow the warnings and instructions may result in serious injury.*

Work Area

- 1. Keep your work area clean and well lit. Cluttered dark areas invite accidents.
- 2. Keep bystanders, children, and visitors away while operating the Sprayer. Distractions can cause you to lose control.

Personal Safety

- 1. Follow all guidelines regarding chemicals sprayed, including MSDS instructions and EPA regulations.
- Stay alert. Watch what you are doing and use common sense when operating the Sprayer. Do not use the Sprayer while tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating the Sprayer may result in serious personal injury.
- 3. **Dress properly.** Do not wear loose clothing or jewelry. Contain long hair. Loose clothes, jewelry, or long hair can be caught in moving parts.
- Do not overreach. Keep proper footing and balance at all times.
 Proper footing and balance enable better control of the tool in unexpected situations.
- 5. Always wear eye protection. Wear ANSI-approved safety goggles.

Use

- 1. Use only with non flammable cleaners, degreasers, penetrating oils, solvents, and lubricants. Not for use with water, or water based materials.
- 2. Release pressure in Bottle by depressing the Trigger or Valve Stem before loosening or removing parts. Contents are under pressure and may spurt forcefully.
- 3. Do not point the Sprayer at yourself, other people or animals.
- 4. Do not allow access to treated areas by people or animals.
- 5. Industrial applications must follow OSHA requirements.
- 6. Make sure the liquid used in the Sprayer is not dirty or sandy.

- 7. This product is not a toy. Do not allow children to play with or near this item.
- 8. Use as intended only.
- 9. Inspect before every use; do not use if parts are loose or damaged.
- 10. Before filling, depress trigger to ensure that it operates properly and does not stick.
- 11. Maintain product labels and nameplates. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.
- 12. The warnings and cautions discussed in this manual cannot cover all possible conditions and situations that may occur. The operator must understand that common sense and caution are factors that cannot be built into this product, but must be supplied by the operator.

Service


- 1. Have your Sprayer serviced by a qualified repair person using only identical replacement parts. *This will ensure that the safety of the tool is maintained.*
- 2. Store idle tools and equipment out of reach of children and other untrained people. Tools and equipment are dangerous in the hands of untrained users.
- 3. Maintain the Sprayer with care. Keep this product clean. A properly maintained Sprayer is easier to control.

SAVE THESE INSTRUCTIONS.

Specifications

Maximum Air Pressure	200 PSI
Operating Pressure	80-150 PSI
Capacity	32 oz.

Components and Controls



Operating Instructions



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

Inspect Sprayer before use, looking for damaged, loose, and missing parts. If any problems are found, do not use Sprayer until repaired.

Follow all guidelines regarding chemicals sprayed, including MSDS instructions and EPA regulations.

Release pressure in Bottle by depressing the Trigger or Valve Stem. Contents are under pressure and may spurt forcefully.

- 1. Before filling, depress trigger to ensure that it operates properly and does not stick.
- 2. Loosen and remove the Filler Cap.
- 3. Pour liquid into the Bottle's top opening. Fill no higher than 2/3 full.

<u>CAUTION!</u> Use only with non flammable cleaners, degreasers, penetrating oils, solvents, and lubricants. Not for use with water, or water based materials.

- 4. Insert the Filler Cap back into the top of the Bottle and tighten.
- 5. Place air chuck (sold separately) on Valve Stem to charge Bottle to 80-150 PSI.

<u>CAUTION!</u> Maximum pressure should not exceed 200 PSI.

6. Depress the Trigger to begin spraying.

7. The Sprayer will depressurize during operation. When the decreased pressure affects the spray pattern, use an air chuck (sold separately) to recharge the Bottle until proper pressure is achieved, then resume spraying.

<u>Note:</u> The spray pattern can be changed from diffuse to a pin stream.

- 8. To change spray pattern from diffuse to a pin stream; unscrew the Pin Stream Nozzle, remove the Spray Nozzle, then reattach the Pin Stream Nozzle and tighten.
- 9. When finished spraying:
 - Depressurize the Sprayer.
 - Dispose of liquid.
 - Clean the Sprayer according to Maintenance Instructions.
 - Store Sprayer indoors out of children's reach.

Inspection, Maintenance, and Cleaning



Procedures not specifically explained in this manual must be performed only by a qualified technician.

AWARNING

Do not use damaged equipment. If abnormal noise, vibration, or leaking air occurs, have the problem corrected before further use.

Follow all guidelines regarding chemicals sprayed, including MSDS instructions and EPA regulations.

Release pressure in Bottle by depressing Trigger or Valve Stem. Contents are under pressure and may spurt forcefully.

- 1. **BEFORE EACH USE**, inspect the general condition of the Sprayer. Check for:
 - · loose hardware
 - · misalignment or binding of moving parts
 - · cracked or broken parts
 - any other condition that may affect its safe operation

- 2. AFTER EVERY USE, clean the Sprayer:
 - a. Follow chemical manufacturer's clean up instructions
 - b. Allow to air-dry.
- 3. PERIODICALLY, lubricate all moving parts of the Sprayer with petroleum jelly.
- 4. Store the Sprayer in a safe, dry, clean location out of reach of children and out of sunlight.

Troubleshooting

Problem	Possible Causes	Likely Solutions
Unit does not spray	1. Not enough liquid in Bottle.	1. Add liquid to Bottle (fill 2/3 max).
	2. Filler Cap is loose.	2. Tighten Filler Cap.
	3. Sprayer not pressurized.	3. Place air chuck (sold separately) on Valve Stem to charge Bottle to 80-150 PSI.
	4. Nozzle is clogged.	4. Disassemble, clean, then reassemble Nozzle.
Spray pattern is undesirable	 Nozzle needs adjustment. Spray fluid contains 	 Remove Spray Nozzle (2) to change to a Pin Stream.
	particles or sand. 3. Nozzle is clogged.	2. Disassemble, clean, then reassemble Nozzle. Empty, clean, then refill bottle with properly strained fluid.
		3. Disassemble, clean, then reassemble Nozzle.



Follow all safety precautions whenever diagnosing or servicing the Sprayer.

Record Product's Serial Number Here:


Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts. Specify UPC 193175473745 when ordering parts.

Parts List and Diagram

Part	Description	Qty
1	Pin Stream Nozzle	1
2	Spray Nozzle	1
3	Head Washer	1
4	Valve Seat Adaptor	1
5	Inner Washer	1
6	Valve	1
7	Valve Spring	1
8	Сар	1

Part	Description	Qty
9	Filler Valve	1
10	Filler Cap	1
11	Cap Gasket	1
12	Bottle	1
13	Sealing Washer	1
14	Guiding Nut	1
15	Trigger	1
16	Cotter Pin	1



PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS DOCUMENT AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



26677 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797