

Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

REV 15I



ITEM 62154

Slim Wall Mount Battery Charger



REV 15I

Visit our website at: <http://www.harborfreight.com>
Email our technical support at: productsupport@harborfreight.com



When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright® 2013 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.
Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

WARNING

Read this material before using this product. Failure to do so can result in serious injury. **SAVE THIS MANUAL.**

Specifications

Battery Types	NiMH only
Input	110-127VAC / 60Hz / 4W

AA Batteries	
1800-2200 mAh	Charging Time: 10-12 Hours
2300-2400 mAh	Charging Time: 12.5 Hours

AAA Batteries	
600-800 mAh	Charging Time: 8-10 Hours
900-1000 mAh	Charging Time: 12.5 Hours

Important Safety Information

To prevent serious injury and property damage:

1. Use as intended only. Use only with NiMH rechargeable batteries. Do not attempt to charge any other type of batteries.
2. Place batteries into Charger in proper polarity and do not install batteries of different types, charge levels, or capacities together.
3. For indoor use only. Do not expose Charger to rain or moisture.
4. Remove from electrical outlet when not in use.
5. Do not use with extension cord.
6. Do not disassemble or open housing.
7. Inspect before every use; do not use if parts are loose or damaged.
8. This product is not a toy. Do not allow children to play with or near this item.
9. Unplug Charger before performing any cleaning. Use only dry cloth for cleaning; do not immerse Charger in water.
10. Properly dispose of all used batteries.
11. Use in only a vertical or floor mounting position.
12. Maintain product labels and nameplates. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.



Charging Instructions



Read the **ENTIRE IMPORTANT SAFETY INFORMATION** section at the beginning of this document including all text under subheadings therein before set up or use of this product.

1. Insert 2 to 4 AA or AAA rechargeable Ni-MH batteries into the battery compartments.
2. Make sure to follow the indicated polarity specified on the battery slots.
3. Plug the Charger into a household electrical outlet. The LED will light up instantly to indicate proper charging is taking place.
4. Remove the batteries after the specified charge time has passed (see Specifications on facing page.) Once batteries are removed, the LED will turn off.
5. If the batteries are not removed earlier, the LED will turn off after about 12.5 hours of charging. Remove batteries once LED turns off.
6. Unplug Charger from outlet. Keep stored in a secure and dry location when not in use.

Record Serial Number Here:

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available for this item.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. **THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.**

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

