

Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

REMOTE CONTROL STUNT CAR



REV 14k

Visit our website at: <http://www.harborfreight.com>
Email our technical support at: productsupport@harborfreight.com

ITEM 62527

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright© 2014 by Harbor Freight Tools®. All rights reserved.

No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠WARNING

**Read this material before using this product.
Failure to do so can result in serious injury.
SAVE THIS MANUAL.**

Specifications

Batteries Required	4x "AA" Batteries (for Car) 1x 9V Battery (for Remote)
Frequency	27/49 MHz (See Product Label)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Important Safety Information

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**
- Follow basic safety precautions to reduce the risk of personal injury and/or damage to the product during use.**
- Do not allow children younger than age 6 to use this Stunt Car.** Children should not operate without adult supervision.
- Do not swing Remote Antenna near your face or near other people.**
- Keep spectators and pets away.** Spectators should only watch from a safe distance.
- Position batteries in proper polarity.** Do not install batteries of different types, charge levels, or capacities together.
- Do not open the Stunt Car's housing or modify its design.** Doing so may cause damage and/or make it dangerous.
- Do not use if parts are loose or damaged.** If the toy has been damaged, immediately stop using it.
- Only use outside or in large, enclosed area.** Do not drive near open flames, pets, or delicate furniture.
- If you lose control of the Stunt Car, release the buttons.**
- The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.
- Maintain product labels and nameplates. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.

Assembly

- Carefully slide the cardboard support containing the Stunt Car out of the packaging.
- Remove the Remote.
- Remove the Stunt Car from the cardboard. If any part does not slide out easily, stop and clear the obstruction before proceeding.

Installing Batteries

Remote

- Unscrew and remove the battery cover on the back of the Remote.
- Insert one 9-Volt battery (not included) into battery compartment, following indicated polarity.
- Replace the Remote battery cover.

Stunt Car

1. Turn the tabs out and remove the battery compartment from the bottom of the Stunt Car. See **Figure A**.
2. Insert four “AA” batteries (not included) into the battery compartment, following the indicated polarity.




Figure A

CAUTION! Replace all batteries at one time. All batteries must be of the same type and charge level.

3. Slide the battery compartment back into the Stunt Car.
4. Turn the tabs inward to lock the battery compartment into place.

Operation

CAUTION! Keep spectators a safe distance away during use.

Note: Take time to get familiar with the controls of the Stunt Car in a safe location.

Note: Read through this section completely and get familiar with the controls BEFORE using Stunt Car.

1. Turn Car Switch on. See **Figure A**. The LED lights in the wheels will light.
2. Place Stunt Car on floor with wheels down.
3. Each Remote button corresponds to one of the rear wheels on the Stunt Car.
4. To move Stunt Car forward, push both buttons towards the antenna (“up”). To move Stunt Car backward, push both buttons away from the antenna (“down”). See **Figure B**.
5. To steer Stunt Car to the right, press the Left button up. To steer Stunt Car to the left, press the Right button up.
6. To stop the Stunt Car, release the buttons.
7. If the Stunt Car rolls onto its back, the small trick wheels will allow it to continue moving.
8. After use, turn Car Switch off. Store indoors, away from water, out of the reach of children.




Figure B

Maintenance

1. Keep the Stunt Car clean and dry.
2. Store the Stunt Car out of the reach of children.
3. Properly recycle all used batteries.

Record Serial Number Here:

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.