

Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

24a

PITTSBURGH[®] **Digital Micrometer**



Visit our website at: <http://www.harborfreight.com>
Email our technical support at: productsupport@harborfreight.com

63647

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-888-866-5797 as soon as possible.

Copyright © 2023 by Harbor Freight Tools®. All rights reserved.

No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠ WARNING

**Read this material before using this product.
Failure to do so can result in serious injury.
SAVE THIS MANUAL.**

Specifications

Display Units	Inches & Millimeters
Accuracy	0.001mm / 0.00005" Resolution 0.004mm / 0.00015" Indicated Error
Capacity	0.00000 ~ 1.00000" 0.000mm ~25.000mm
Power Supply	3V CR2032 (Included)

IMPORTANT SAFETY INFORMATION

1. Wear ANSI-approved safety goggles during use.
2. Keep work area clean and well lit.
3. Do not operate when tired or when under the influence of alcohol, drugs or medication.
4. Use as intended only.
5. Inspect before every use; do not use if parts are loose or damaged.
6. This product is not a toy. Keep it out of reach of children.
7. Maintain product labels and nameplates. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.

Button/Coin Battery Warnings

WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



This symbol means:

INGESTION HAZARD: This product contains a button cell or coin battery.

1. Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
2. Even used batteries may cause severe injury or death.
3. Call a local poison control center for treatment information.
4. Non-rechargeable batteries are not to be recharged.
5. Do not force discharge, recharge, disassemble, heat above 158°F or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
6. Ensure the batteries are installed correctly according to polarity (+ and -).
7. Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
8. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
9. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.



SAVE THESE INSTRUCTIONS.

Components and Controls



Operating Instructions



Read the **ENTIRE IMPORTANT SAFETY INFORMATION** section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

1. Install battery by removing screw(s) and opening battery compartment. Install CR2032 battery in correct polarity, close compartment and replace screw(s).
2. Use a clean, lint-free cloth to clean the Anvil of the Micrometer and the object being measured.
3. Turn on. Choose inch or mm. To switch from inches to millimeters, hold the ABS-in/mm button for five seconds to change from one to other.

Note: When the ABS-in/mm button is pressed, the display automatically resets to zero and takes measurements from whatever the previous position was.

4. Rotating the Thimble counterclockwise, open the Anvil until it is wider than the object to be measured.

5. Place the Anvil around the object and turn the Thimble clockwise until the Anvil just touches the object.
6. Turn the Ratchet Stop clockwise to close the Anvil on the object being measured until it clicks. To avoid damage to either the Micrometer or the workpiece, only use the Ratchet Stop to close the Anvil of the Micrometer on the object.
7. Turn the Thimble Lock clockwise to lock the measurement and carefully withdraw the Micrometer from the object.
8. This Micrometer measures items in hundred thousandths of an Inch. View the Display to see the results.
9. To reset to zero, hold the ON/OFF/SET button for five seconds.

Note: This is a delicate instrument. The Micrometer should be handled carefully. Dropping this product could damage it, and may effect accuracy.

10. To prevent accidents, turn off the tool after use. Clean, then store the tool indoors out of children's reach.

Record Product's Serial Number Here:_____

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available for this item. Refer to UPC 193175510181.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

PITTSBURGH

26677 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797