

Specifications

	,
Input Rating	6VDC, 500mA
Battery	Li-ion
Battery Rating	3.7V, 2000mAh
Charge Time	4.5 hours

IMPORTANT SAFETY INFORMATION

AWARNING

To prevent serious injury, FIRE, and EXPLOSION:

- Keep dry. Do not open, drop, short-circuit, incinerate, expose to temperatures higher than 140° F, or charge/use if damaged.
- 2. Only use included charging adaptors. Other adaptors may damage tool or cause fire.
- 3. Do not submerge Light.

- Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.
- 6. Not a toy. Keep out of reach of children.

Lithium Battery Safety Warnings



LITHIUM BATTERIES STORE A LARGE AMOUNT OF ENERGY AND WILL VENT FIRE OR EXPLODE IF MISTREATED:



- 1. Keep Work Light dry.
- 2. DO NOT DO ANY OF THE FOLLOWING TO THE BATTERY PACK:
 - a. Open,
 - b. Drop,
 - c. Short-circuit,

- d. Puncture,
- e. Incinerate, or
- f. Expose to temperatures greater than 140°F.
- 3. Charge Work Light only according to these instructions.

Charging Instructions



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

- 1. Insert the end of the Adaptor cord into the Charging Jack, located in one of the handgrips.
- Plug the AC/DC Adaptor into a 120V outlet or plug the Cigarette Lighter Adaptor into any 12V DC outlet in an automobile, boat or RV.
- The Charge Light Indicator will light up Red during charging. After approximately 4.5 hours the Charge Light Indicator turns Green, indicating the Work Light is fully charged and ready for use. Unplug the Adaptor.

NOTICE: Do not leave the Battery in a discharged state. Charge the Battery every 3 months if the Work Light is not in use. This will keep the Battery from wearing down and add to its life. Do not charge the Work Light at temperatures below 40° F.

Operation Instructions



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this document including all text under subheadings therein before set up or use of this product.

NOTE: Before using Work Light for the first time, fully charge the Battery.

- 1. Press one of the buttons once to turn on the light in economy mode.
- 2. Press one of the buttons again to switch the light to maximum brightness.
- To hang the Work Light, access the magnetic stretch cord attachment end caps by unscrewing the caps located on the end of each handgrip. Use the magnetic ends to attach the Work Light to a vehicle or other metal object. The magnetic end caps also contain fold-away attachment hooks for additional hanging options.
- 4. Press one of the buttons a third time to turn the light off.
- 5. When finished using the Work Light, store indoors away from children.

NOTICE: Do not open the housing, there are no user-serviceable parts inside.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Record Product's Serial Number Here:

Note: If product has no serial number, record month and year of purchase instead.

Note: Replacement parts are not available for this item.

BRAUN

3491 Mission Oaks Blvd. • PO Box 6009 • Camarillo, CA 93011 • 1-888-866-5797