


Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's date code in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

25j

BRAUN™

TACTICAL RAIL MOUNT LED LIGHT



BRAUN is trademark of Harbor Freight Tools.
All other marks are trademarks
of their respective owners.

Visit our website at: <https://www.harborfreight.com>
Email our technical support at: productsupport@harborfreight.com

70460

When unpacking, make sure that the product is intact and undamaged. If any parts are missing or broken, please call 1-800-444-3353 as soon as possible.

Copyright © 2025 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

⚠ WARNING

Read this material before using this product. Failure to do so can result in serious injury. **SAVE THIS MANUAL.**

Specifications

Battery	Li-Ion CR123A x2
Runtime	Up to 1 hr 30min
Light Projection Range	Up to 850ft
Lumens	1000

IMPORTANT SAFETY INFORMATION

⚠ DANGER

TO PREVENT SERIOUS INJURY AND DEATH:

1. Before attaching, inspecting, or servicing a weapon mounted light: Engage safety on weapon. Unload weapon and remove magazine if applicable. Inspect chamber and confirm it is empty.
2. To prevent temporary or permanent loss of sight, do not focus beam using additional lens, stare into beam, or shine beam into eyes.
3. Keep dry. Do not submerge Light.
4. Use of light in strobe mode may cause seizure in persons with photosensitive epilepsy.
5. Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
6. Not a toy. Keep out of reach of children.
7. USE ONLY CR123A non-rechargeable batteries. DO NOT install new and used batteries together. DO NOT install different battery types or battery brands together. Doing so may result in leakage, fire, or explosion with risk of serious personal injury. DO NOT recharge, misuse, short circuit, improperly store or discard, disassemble, or heat above 212°F (100°C). Keep away from children.

Setup - Before Use:



Read the **ENTIRE** IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.


⚠ DANGER

TO PREVENT SERIOUS INJURY AND DEATH:

Before attaching, inspecting, or servicing a weapon mounted light: Unload weapon and remove magazine if applicable. Inspect chamber and confirm it is empty. Engage safety on weapon.

Battery Installation/Replacement

1. Pull Tab up, then open Battery Compartment Cover.
2. Remove old batteries. Batteries must be recycled or disposed of properly.
3. Insert new batteries, noting proper polarity.
4. Close Battery Compartment Cover, then push Tab down until it locks.




Mounting


Glock style Adapter comes installed.

1. To change Adapter:

- a. Remove Bolt, Washer, and Adapter.
Remove Nut from Adapter




- b. Place Nut into Adapter. Make sure Nut is flush with top of Adapter. Turn Adapter over and install Adapter.




- c. Replace Washer and Bolt.

2. Select Adapter for weapon rail style:

- a. GL - Glock style (installed)
b. 1913 - Mil Std-1913 Picatinny
c. P320 - Sig Sauer P320
d. 90two - Beretta 90 Two
e. TSW/99 - Smith & Wesson 99



3. Loosen Clamp Screw. Place light around the weapon's rail. Tighten Clamp Screw.




Operation Instructions



Read the **ENTIRE IMPORTANT SAFETY INFORMATION** section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

1. Toggle Switch to the RIGHT to turn Light ON.
2. Toggle Switch to the LEFT to turn Light OFF.
3. Toggle Switch to the LEFT to turn Light ON momentarily.
4. Toggle Switch to the LEFT twice to turn Strobe ON momentarily.



DANGER! TO PREVENT SERIOUS INJURY AND DEATH: When finished using Tactical Light, Unload weapon and remove magazine if applicable. Inspect chamber and confirm it is empty. Engage safety on weapon.

5. Remove Light from weapon. Store indoors away from children.

NOTICE: Do not open the housing, there are no user-serviceable parts inside.

Maintenance and Servicing Instructions



Procedures not specifically explained in this manual must be performed only by a qualified technician.

1. **BEFORE EACH USE**, inspect the general condition of the light. Check for:
 - loose hardware,
 - misalignment or binding of moving parts,
 - cracked or broken parts, and
 - any other condition that may affect its safe operation.
2. **AFTER USE**, wipe external surfaces of the tool with clean cloth. Use a soft cloth and mild detergent to clean Lens. Do not use aggressive cleaning solutions or solvents.

Record Product's Date Code Here: _____

Note: If product has no date code, record month and year of purchase instead.

Note: Replacement parts are not available for this item. Refer to UPC 193175597694.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

BRAUN™

26677 Agoura Road • Calabasas, CA 91302 • 1-800-444-3353