



12 L.E.D. DYNAMO WIND-UP LANTERN

Model 96200

OPERATION INSTRUCTIONS



Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein.

Distributed exclusively by Harbor Freight Tools®.

3491 Mission Oaks Blvd., Camarillo, CA 93011

Visit our website at: <http://www.harborfreight.com>



**Read this material before using this product.
Failure to do so can result in serious injury.**

SAVE THIS MANUAL.

Copyright© 2007 by Harbor Freight Tools®. All rights reserved.
No portion of this manual or any artwork contained herein
may be reproduced in any shape or form without the express
written consent of Harbor Freight Tools.

For technical questions or replacement parts, please call 1-800-444-3353.

SPECIFICATIONS

Power Source	Hand Crank
Battery	Three NI-CD 2/3AA 300mAh 3.6V
Number of L.E.D.s	12
Handle features	Foldaway handle and hanging hook
Dimensions	10-1/2" H x 4-7/8" Dia.
Weight	1.2 lbs

Save This Manual

You will need this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures, parts list and assembly diagram. Keep your invoice with this manual. Write the invoice number on the inside of the front cover. Write the product's serial number in the back of the manual near the assembly diagram, or write month and year of purchase if product has no number. Keep this manual and invoice in a safe and dry place for future reference.

GENERAL SAFETY RULES

1. **Stay alert.** Watch what you are doing, and use common sense when operating this appliance. Do not use a this appliance while tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating could result in serious personal injury.
2. **Dress properly.** Do not wear loose clothing or jewelry. Contain long hair. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts.
3. **Do not overreach.** Keep proper footing and balance at all times. Proper footing and balance enables better control of the appliance in unexpected situations.
4. **Store idle appliances out of reach of children and other untrained persons.** Appliances are dangerous in the hands of untrained users.
5. **Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the appliance's operation.** If damaged, have the appliance serviced before using. Many accidents are caused by poorly maintained appliances.
6. **Maintain labels and nameplates on the appliance.** These carry important information. If unreadable or missing, contact Harbor Freight Appliances for a replacement.
7. **Do not expose the Dynamo Lantern to rain or wet conditions.** Water entering electrically powered equipment will increase the risk of electric shock.

UNPACKING

When unpacking, check to make sure that the item is intact and undamaged. If any parts are missing or broken, please call Harbor Freight Appliances at the number shown on the cover of this manual as soon as possible.

OPERATION INSTRUCTIONS

PLEASE READ THE FOLLOWING CAREFULLY

1. The Dynamo Lantern has a push button On/Off. Press the Button to OFF before charging the Dynamo Lantern. Pull out the Handle. **Note:** The push button ON/OFF also controls the number of L.E.D's that can be used. Pushing the button once turns on four L.E.D's, twice - eight L.E.D's, third time - twelve L.E.D's and the fourth time shuts all the L.E.D's off.
2. Grasp the Handle and crank it continuously clockwise for at least 1 minute. One minute of cranking the Handle will generate a varying amount of light depending on how many L.E.D.s are used.

One minute cranking produces: 4 L.E.D.s for 20 minutes, 8 L.E.D.s for 15 minutes, or 12 L.E.D.s for 10 minutes.

3. When L.E.D.s are charged, fold handle back into the recess.
4. Press the On/Off Button to ON to turn on the Dynamo Lantern. **Note:** The push button ON/OFF also controls the number of L.E.D's that can be used. Pushing the button once turns on four L.E.D's, twice - eight L.E.D's, third time - twelve L.E.D's and the fourth time shuts all the L.E.D's off.

Battery Disposal

1. **DISPOSAL:** The Dynamo Lantern uses a rechargeable NiCd battery. Do not attempt to replace battery. Remove all screws from case and open. Cut wires from battery with insulated wire clippers and remove battery. Disposing of the battery must comply with the standards for hazardous waste disposal in your community. Contact your local city government office for the nearest hazardous waste disposal area in your community.

Part	Description
1	Crank
2	Handle
3	Hook

Part	Description
4	L.E.D.s
5	ON/OFF Button



THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE APPLIANCE ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Record Product's Serial Number Here: _____

Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.

LIMITED 90 DAY WARRANTY

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. **THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.**

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

3491 Mission Oaks Blvd. • PO Box 6009 • Camarillo, CA 93011 • (800) 444-3353