

# HEAD LAMP MAGNIFIER

58788


UPC 193175446626

22h

## SPECIFICATIONS

Batteries	3x AA (sold separately)
Magnification	1.5x, 2x, 3.5x, 8x, 9.5x, 11.5x

## FUNCTIONS



## IMPORTANT SAFETY INFORMATION


1. **⚠️ WARNING! To prevent serious injury, including temporary or permanent loss of sight:** Do not focus beam using additional lens, stare into beam, or shine beam into eyes.
2. Keep away from children.
3. Contains small parts.
4. Use as intended only.
5. Inspect before every use; do not use if parts damaged.

## INSTRUCTIONS ON OTHER SIDE

For technical questions, please call 1-888-866-5797.

## OPERATION

1. Install Batteries and place Head Lamp on head.
2. Press Power Switch turn the Lights on to low brightness, press again for high brightness, and press a third time to turn the Lights off.
3. Pull out rear Headband Knob and rotate as needed to adjust tightness. Push Knob back in to lock setting.
4. Turn side Tilt Knobs to adjust angle of Frame.
5. Set magnification:
  - a. By installing/removing lenses from bottom of Head Lamp. Squeeze both sides of 1.5x / 2x Lens and pull out to remove. Slide in to install.
  - b. Move 8x Lens in front for use. When finished, fold back to resting position.
6. Pivot Battery Compartment as needed to aim Lights.




## REPLACING BATTERIES

1. Pull out Battery Compartment and slide off Battery Cover.
2. Remove old batteries and replace with same following polarity.
3. Slide on Battery Cover, then install Battery Compartment until it clicks in securely.

**CAUTION:** Do not install old and new batteries together. Do not install alkaline, carbon-zinc or rechargeable batteries together. Position batteries in proper polarity. Do not use swollen or leaking batteries.

**Note:** Remove batteries if storing Head Lamp for extended period.



For technical questions, please call 1-888-866-5797.