Owner's Manual & Safety Instructions

Save This Manual Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.



any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

Failure to do so can result in serious injury. SAVE THIS MANUAL.

19f

Table of Contents

Safety	2
Specifications	8
Setup	6
Operation	10

Maintenance	9
Parts List and Diagram	18
Warranty	12



	WARNING SYMBOLS AND DEFINITIONS
	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE CAUTION	Addresses practices not related to personal injury.

IMPORTANT SAFETY INFORMATION

General Power Tool Safety Warnings

AWARNING

Read all safety warnings and all instructions.

Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your battery-operated (cordless) power tool.

MAINTENANCE

Air Compressor Safety Warnings

- 1. Risk of fire or explosion do not spray flammable liquid in a confined area or towards a hot surface. Sprav area must be well-ventilated. Do not smoke while spraying or spray where spark or flame is present. Arcing parts - keep compressor at least 20 feet away from explosive vapors, such as when spraying with a spray gun.
- 2. Risk of bursting do not adjust regulator higher than marked maximum pressure of attachment.
- 3. Risk of injury do not direct air stream at people or animals.
- 4. Do not use to supply breathing air.
- 5. Do not leave compressor unattended for an extended period while powered. Disconnect power from compressor after working.
- 6. Keep compressor well-ventilated. Do not cover compressor during use.
- Do not remove the valve cover or adjust internal components.
- 8. Do not use the air hose to move the compressor.
- 9. The use of accessories or attachments not recommended by the manufacturer may result in a risk of injury to persons.
- 10. All air line components, including hoses, pipe, connectors, filters, etc., must be rated for a minimum working pressure of 150 PSI, or 150% of the maximum system pressure, whichever is greater.
- 11. Maintain labels and nameplates on the compressor. These carry important safety information. If unreadable or missing, contact Harbor Freight Tools for a replacement.

- 12. This product is not a toy. Keep it out of reach of children.
- 13. Wear ANSI-approved safety goggles and heavy-duty work gloves during use.
- 14. Do not expose to rain or wet conditions.
- 15. People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.
- 16. Do not leave the tool unattended when the Battery Pack is connected. Turn off the tool, and remove the Battery Pack before leaving.

17.

The battery Charger gets hot during use. The Charger's heat can build up to unsafe levels and create a fire hazard if it does not receive adequate ventilation, due to an electrical fault, or if it is used in a

hot environment.

Do not place the Charger on a flammable surface. Do not obstruct any vents on the Charger. Especially avoid placing the Charger on carpets and rugs; they are not only flammable, but they also obstruct vents under the Charger. Place the Charger on a stable, solid, nonflammable surface (such as a stable metal workbench or concrete floor) at least 1 foot away from all flammable objects, such as drapes or walls. Keep a fire extinguisher and a smoke detector in the area. Frequently monitor the Charger and Battery Pack while charging.

18. The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product. but must be supplied by the operator.

Battery tool use and care

- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the power tool. Carrying the power tool with your finger on the switch or energizing power tool that have the switch on invites accidents.
- Disconnect the battery pack from the power tool before making any adjustments, changing accessories, or storing power tool. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- Use power tools only with specifically designated battery packs. Use of any other battery packs may create a risk of injury and fire.
- 5. When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or a fire.

- Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.
- Do not use a battery pack or power tool that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not expose a battery pack or power tool to fire or excessive temperature. Exposure to fire or temperature above 265°F may cause explosion.
- 9. Follow all charging instructions and do not charge the battery pack or power tool outside of the temperature range specified in the instructions. Charging improperly or at temperatures outside of the specified range may damage the battery and increase the risk of fire.
- Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- Do not modify or attempt to repair the power tool or the battery pack except as indicated in the instructions for use and care.

Lithium Battery Safety Warnings



LITHIUM BATTERIES STORE A LARGE AMOUNT OF ENERGY AND WILL VENT FIRE OR EXPLODE IF MISTREATED:



- 1. Keep Battery Pack dry.
- 2. DO NOT DO ANY OF THE FOLLOWING TO THE BATTERY PACK:
 - a. Open,
 - b. Drop,
 - c. Short-circuit,
 - d. Puncture,
 - e. Incinerate, or
 - f. Expose to temperatures greater than 265°F.

- 3. Charge Battery Pack only according to its Charger's instructions.
- 4. Inspect Battery Pack before every use; do not use or charge if damaged.
- 5. Li-Ion BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.
- SAVE THESE INSTRUCTIONS.

TO PREVENT ELECTRIC SHOCK AND DEATH FROM INCORRECT GROUNDING: Check with a qualified electrician if you are in doubt as to whether the outlet is properly grounded. Do not modify the power cord plug provided with the charger. Do not use the charger if the power cord or plug is damaged. If damaged, have it repaired by a service facility

before use. If the plug will not fit the outlet, have a proper outlet installed by a qualified electrician.

Extension Cords

Note: Extension cords must not be used with this item's Charger.

Symbology

PSI	Pounds per square inch of pressure
BAR	Measure of atmospheric pressure on Earth at sea level
kPa	Kilopascal is a unit of pressure measurement
CFM	Cubic Feet per Minute flow
SCFM	Cubic Feet per Minute flow at standard conditions
NPT	National pipe thread, tapered
NPS	National pipe thread, straight

	Double Insulated
V	Volts
~	Alternating Current
Α	Amperes
	WARNING marking concerning Risk of Explosion. Do not puncture, short, or open battery packs and do not charge damaged battery packs.
	WARNING marking concerning Risk of Fire. Do not cover Charger ventilation ducts. Charge on fireproof surface only.

Specifications

Charger Input Rating	120VAC / 60Hz
Battery Type	Bauer 20V Li-Ion (sold separately)
Air Pressure	160 PSI (max)

Setup - Before Use:



Read the <u>ENTIRE</u> IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Note: For additional information regarding the parts listed in the following pages, refer to *Parts List and Diagram* on page 11.

Functions



Operating Instructions



Read the ENTIRE IMPORTANT SAFETY INFORMATION section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Battery Charging

Charge battery after unpacking and before using this tool. Follow instructions included with battery charger (sold separately).

Work Area Set Up

- Designate a work area that is clean and well lit. The work area must not allow access by children or pets to prevent distraction and injury.
- 2. There must not be objects, such as utility lines, nearby that will present a hazard while working.

WARNING! TO PREVENT INJURY AND BLINDNESS, wear ANSI-approved eye protection during use.


 Insert a fully charged Battery Pack, making sure it clicks into place.



- Inflating Car Tires: Remove the tire's valve cap. Move the Tire Inflator's Lever straight up and push it over tire's valve stem. Move the Lever to the locked position.
- 3. Inflating Bicycle Tires:
 - a. Schrader Valve Remove tire's valve cap. Move Tire Inflator's Lever straight up and push it over the tire's valve stem. Move the Lever to the locked position.
 - b. Presta Valve Remove tire's valve cap. Open the valve tip. Thread Presta Valve Adapter on to valve stem. Move Tire Inflator's Lever straight up and push it over the Presta Valve Adapter. Move the Lever to the locked position.

<u>NOTICE:</u> Lock Tire Inflator firmly in place before turning on the Inflator.

- 4. Inflating Small Inflatables:
 - a. Move Tire Inflator's Lever straight up and insert adapter. Move the Lever to the locked position.



- b. Connect adapter to item to be inflated.
- 5. WARNING! TO PREVENT SERIOUS INJURY AND DEATH FROM EXPLOSION: <u>Before</u> inflating, check item manufacturer's recommended air pressure. Do not <u>exceed that pressure</u>. Over inflation may result in an explosion.
- 6. To start inflating, squeeze the Trigger.
- 7. Stop inflating briefly and use the **built-in Pressure Gauge** to measure air pressure.

NOTICE: The Inflator can become hot during use. Allow the Inflator/Deflator to cool for 15 minutes after 10 minutes of continued use.

NOTE: When inflating items to 10 PSI or less, inflate in short bursts and check item's pressure after each burst.

- 8. To stop inflating, release the Trigger.
- Disconnect inflatable and remove Battery Pack after use. Clean, then store the unit indoors out of children's reach.

NOTE: Allow Inflator to cool 30 minutes before storing away.

Maintenance and Servicing



Procedures not specifically explained in this manual must be performed only by a qualified technician.

AWARNING

TO PREVENT SERIOUS INJURY FROM ACCIDENTAL OPERATION: Make sure that the Trigger is in the off-position and remove its Battery Pack before performing any procedure in this section.

TO PREVENT SERIOUS INJURY FROM TOOL FAILURE: Do not use damaged equipment. If abnormal noise or vibration occurs, have the problem corrected before further use.

Cleaning, Maintenance, and Lubrication

- 1. BEFORE EACH USE, inspect the general condition of the tool. Check for:
 - · leaking, swollen, or cracked battery pack,
 - · loose hardware.
 - · misalignment or binding of moving parts,
 - · cracked or broken parts, and
 - · any other condition that may affect its safe operation.
- 2. AFTER USE, wipe external surfaces of the tool with clean cloth.

- 3. Using vacuum, clean debris from the external air vents
- 4. Li-lon BATTERY MUST BE RECYCLED OR **DISPOSED OF PROPERLY.** Do not open crush, heat above 140° F or incinerate.
- 5. Disconnect battery pack and store battery pack, charger, and tool in dry, indoor area out of reach of children and away from metal objects (i.e., paperclips, coins) to prevent shorting.

Troubleshooting

Problem	Possible Causes	Likely Solutions
Tool will not start.	 Battery Pack not properly connected. 	 Remove Battery Pack, make sure there are no obstructions, reinsert the Battery Pack according to its shape (it should only fit one way), and press firmly until the Battery Pack locks in place.
	 Battery Pack not properly charged. 	 Make sure Charger is connected and operating properly. Give enough time for Battery Pack to recharge properly.
	3. Battery Pack burnt-out.	 Dispose of old Battery Pack properly or recycle. Replace Battery Pack.
	4. Internal damage or wear.	4. Have technician service tool.
Tool operates slowly.	1. Forcing tool to work too fast.	1. Allow tool to work at its own rate.
	2. Battery Pack wearing out.	2. Dispose of old Battery Pack properly or recycle. Replace Battery Pack.
Excessive noise or rattling.	Internal damage or wear.	Have technician service tool.
Overheating.	1. Forcing tool to work too fast.	1. Allow tool to work at its own rate.
	2. Blocked motor housing vents.	2. Using vacuum, clean debris from Air Intake vents

Follow all safety precautions whenever diagnosing or servicing the tool. Disconnect Battery Pack and Charger power supply before service.

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Parts List and Diagram

Part	Description	Qty
1	Pressure Gauge Cover	1
2	Pressure Gauge	1
3	Left Housing	1
4	Tire Inflator	1
5	Ball Needle Adapter	1
6	Tapered Adapter	1
7	Tube	1
8	Hose Clamp	2
9	Rubber Foot	2

Part	Description	Qty
10	Pump Assembly	1
11	Switch	1
12	Trigger	1
13	Presta Adapter	1
14	Right Housing	1
15	Hose	1
16	Self-Tapping Screw	2
17	Protector Panel	1

4

13

14

6

15

1 1


12

Ř

8

10

17



Record Product's Serial Number Here:_

Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.

Limited 90 Day Warranty

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



26541 Agoura Road • Calabasas, CA 91302 • 1-888-866-5797