




CAMPING TABLE

Tabletop Weight Capacity (including 5lb capacity for each cup holder)	50 lb
Bottom Shelf Weight Capacity	40 lb



CAUTION! TO PREVENT INJURY: Do not exceed weight capabilities.

1. Open Leg/Shelf assembly completely and place on flat, level, hard and smooth surface capable of safely supporting the Table and the items on it.
2. Open Tabletop until hinges lock it in place. Line up exposed Tubing on bottom of Tabletop with Clips on top of Legs. Press Tubing in until securely seated into Clips.
3. Gently push each mesh cup holder down.
4. When finished, store in a clean dry location out of reach of children.