

WINDSHIELD REMOVAL KIT

Specifications

Hook Tool: 13" L X 4" W
T-Handle Grips: (2) 3-7/8" L x 1" Dia.
Wire: Braided, 72 ft. x .027"

Note: Two people are needed to properly use this product.

Safety Warnings And Precautions

When using tool, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.


1. **Keep work area clean.** Cluttered areas invite injuries.
2. **Observe work area conditions.** Do not use tools in damp or wet locations. Keep work area well lighted.
3. **Keep children away.** Never let children touch or play with tools. When not in use, store in a secure and dry location.
4. **Store idle equipment.** When not in use, tools must be stored in a dry location to inhibit rust. Always lock up tools and keep out of reach of children.
5. **Use the right tool for the job.** Do not attempt to force a small tool or attachment to do the work of a larger industrial tool. There are certain applications for which this tool was designed. It will do the job better and more safely at the rate for which it was intended. Do not use this tool for a purpose for which it was not intended.
6. **Do not overreach.** Keep proper footing and balance at all times. Do not reach over or across running machines.
7. **Use eye and hand protection.** Wear ANSI-approved safety goggles and heavy-duty work gloves during use.
8. **Maintain tools with care.** Keep tools sharp and clean for better and safer performance. Inspect braided wire periodically and, if damaged, have it replaced. The handles must be kept clean, dry, and free from oil and grease.
9. **Stay alert.** Watch what you are doing, use common sense. Do not operate any tool when you are tired.
10. **Check for damaged parts.** Before using any tool, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Any part that is damaged should be properly repaired or replaced by a qualified technician.
11. **Do not operate tool if under the influence of alcohol or drugs.** Read warning labels if taking prescription medicine to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not operate the tool.
12. **Wear leather gloves when handling glass wind shields and braided wire.**
13. **Use an assistant to help carry glass windshields.**
14. **Before removing the windshield; always protect your vehicle's finish and interior by using appropriate covers over hood/fender area and seats/dashboard.**

Warning: The warnings, cautions, and instructions discussed here cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.



Operation

Two people are needed to use this product and to safely handle and remove old windshield.

1. Park the vehicle in a location with plenty of light, set the emergency brake, and turn off the engine.
2. Carefully pop-off and remove any windshield trim covering the edge of the windshield.
3. Cut about two to three feet of Braided Wire.
4. Place the wire into the groove of the Hook Tool, near the wire end, as shown below.



5. Bend the wire over the end of the Hook Tool.
6. Working from the outside of the vehicle, force the wire between the windshield and the frame to which it is glued.
7. Pull the Hook Tool out, leaving the wire behind.
8. From the inside of the vehicle, pull the wire through to one half its length.
9. Attach the T-Handle Grips to each end of the wire:
 - a.) Push the T-Handle Grip Attachment Post to the opposite end of the Handle to open it.
 - b.) Push the end of the wire into the Attachment Post and feed it into the grip hole.
 - c.) Push the Attachment Post back into the T-Handle so that the wire cannot be pulled out. (See below.)



10. With the help of another person, grab each T-Handle Grip (one on the inside of the vehicle, and one on the outside) and pull the wire along the perimeter of the windshield, separating it from the vehicle frame and glue.
11. When the old windshield is separated, carefully lift the windshield off the vehicle and set in a safe location.
- Warning: Avoid cuts. Use care if the windshield is cracked or broken. It may shatter when lifted.**
12. Scrape off all old glue from the vehicle windshield frame, and prepare for installation of the new windshield.